



INSTALLING THE GROHE FITTINGS
 THE MARKING LINE FOR THE SUPPORTS
 MUST BE AT THE METRE LINE
 220 MM FROM THE OUTER
 SURFACE TO THE SUPPORT WALL

MEASUREMENTS TAKEN
 AT THE MEASURING LINES